


Model


Mini Cooper S (R53) since 2002

**RESET**




20034

**VIDANGE**




20035

## PERIODIC INSPECTION




20036

## BRAKE FLUID



20037

# WARNING LIGHT



20038

## **RESET**

Switch ignition off.

Press and hold the button for resetting the trip recorder display and simultaneously put the key on the (1) position.

After (5) second(s), the display shows the SIA status (drain or check).

Release the button for resetting the trip recorder display.

Press and hold the button for resetting the trip recorder display for (5) seconds.

The display flashes and shows the text 'RST'.

Release the button for resetting the trip recorder display.

## **VIDANGE**

Press and hold the button for resetting the trip recorder display for (5) seconds.

The display flashes and shows the text 'RST'.

After (5) flashes, the display switches to periodic mode.

If the reset button is pressed again during these flashes, the current interval will be reset right away and the display will show the nw status for (5) second(s) before to switch to inspection interval data.

The check/drain data are then reset.

## **PERIODIC INSPECTION**

Press and hold the button for resetting the trip recorder display for (5) seconds.

The 'RST' text will blink but at this point the spanner symbol will be displayed.

Press again on the trip recorder button during the (5) flashes to reset the inspection intervals.

The display will show the new periodic interval during (5) second(s) before to display 'END' during (2) other seconds.

The display will return on the trip and total recorder.

## **BRAKE FLUID**

Number of days remaining before replacing the brakes fluid (A).

## **WARNING LIGHT**

Replace the brake pads.